

**FLOW DIAGRAM- FROM POTHAKALANVILLAI SUMP TO PERIATHALAI ZONE( 48 HABITATIONS)**

SITHANKUDIRIPPU ZONE 19HAB					
UNION	HAB	5	10	30	60
SA	18	2	4	6	1
UDA	1	-	1	-	-
TOTAL	19	3	4	6	1

CHETTIVILAI ZONE 29HAB				
UNION	HAB	10	30	60
SA	29	5	8	5
TOTAL	29	5	8	5

PERVATHALLI ZONE 2 HAB			
UNION	HAB	30	60
SA	2	1	1
TOTAL	2	1	1